


TELFORD CORNER DESK ASSEMBLY INSTRUCTIONS

Thank you for purchasing the Telford Corner Desk.

Please read the instructions carefully to ensure safe operation of this product.



Size: 118 x 39.6 x 76.5 cm (WDH)

Colour: Dark Oak/Black or Light Oak/Grey or Concrete/Black



Finish: Foil or Melamine

PLEASE READ this sheet prior to assembly to familiarise yourself with the various stages of construction.

Carefully open the pack supplied and check the contents against the parts and fittings check list. Do not destroy any of the packaging until you are certain that you have all the necessary parts for the assembly.

CAUTION: there are small components used in the construction of this unit. These loose items should be kept away from young children whilst assembling your unit to avoid the danger of choking.

Tools Required



1 Hour
Set Up

PO No : _____

Version 1 - 201026

Page 1 of 12

IMPORTANT - READ CAREFULLY - RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

INFORMATION

- This product is designed to hold 15 Kg in total, spread evenly over the whole unit.
- Do not exceed this weight.
- We recommend that this unit is assembled in the room intended for use.
- When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.
- Unwrap all packaging materials and place the components on top of the carton box or on a clean floor to prevent them from scratching.
- Check the pack and make sure you have all the parts listed.
- Ensure that this product is fully assembled as illustrated before use.
- Check all screws or bolts are tightened and inspect regularly
- Tools not included unless specified in parts list.

WARNINGS

- This product should only be used on a firm and level floor.
- Keep small parts out of reach of children.
- Make sure the legs are always in contact with the floor.
- DO NOT use power tools to construct this product.
- DO NOT tighten screws until parts are assembled or as advised in this guide.
- DO NOT over tighten screws or bolts.
- DO NOT use this product if parts are missing, damaged or worn.
- DO NOT sit or stand on the product.
- The desk is free standing and stable but we supply wall connection brackets to stop the product tipping over in extreme circumstances. If you have young children in the home it is better that the desk is fixed safely to a wall to prevent any potential accidents - please refer to Step 9.
- N.B. When drilling the wall to fix the anti-tilt bracket, always make sure the area to be drilled is free from hidden electrical wiring or gas / water pipes .
- Carefully assess the suitability of the wall to ensure that the fastening device will withstand the load and forces generated. Walls can be quite different in construction so fixings are not supplied - choose the most suitable fixing for your wall type - if in doubt consult an expert.

CARE INFORMATION


- To clean, wipe with a damp cloth.
- Never use scourers, abrasives or chemical cleaners.
- Do not use solvent based cleaners or detergents as they can bleach or damage the product.

TELFORD CORNER DESK ASSEMBLY INSTRUCTIONS

Parts and Fittings Checklist

Please check the pack contents before assembling the product. If any components are missing, please contact your retailer.

The fittings pack contains small items that should be kept away from children.



TELFORD CORNER DESK ASSEMBLY INSTRUCTIONS


All parts are packed in one carton

1	2	3
Description: Top Panel Qty: 1 Size: 1180 x 396 x 15 mm Carton No: 1/1	Description: Base Panel Qty: 1 Size: 1180 x 396 x 15 mm Carton No: 1/1	Description: Side Panel Qty: 2 Size: 478 x 100 x 15 mm Carton No: 1/1
4	5	6
Description: Front Cross Bar Qty: 1 Size: 932 x 80 x 20 mm Carton No: 1/1	Description: Centre Upright Qty: 2 Size: 300 x 100 x 15 mm Carton No: 1/1	Description: Rear Cross Bar Qty: 1 Size: 525 x 80 x 20 mm Carton No: 1/1
7	8	9
Description: Drawer Front Qty: 1 Size: 448 x 98 x 15 mm Carton No: 1/1	Description: LH Drawer Side Qty: 1 Size: 320 x 98 x 15 mm Carton No: 1/1	Description: RH Drawer Side Qty: 1 Size: 320 x 98 x 15 mm Carton No: 1/1
10	11	12
Description: Drawer End Qty: 1 Size: 416 x 95 x 15 mm Carton No: 1/1	Description: Drawer Base Qty: 1 Size: 424 x 313 x 3 mm Carton No: 1/1	Description: Metal Leg Frame Qty: 2 Size: 633 x 470 x 20 mm Carton No: 1/1

TELFORD CORNER DESK ASSEMBLY INSTRUCTIONS


Fittings (to scale)

Code	Item	Quantity
A	Cam Bolt (38mm overall)	14
B	Cam Lock	14
C	Dowel 8x30mm	16
D	Carcass Screw for Fitting Centre Upright and Side Panels to Base Panel M7x50mm	10
E	Screw for Fitting Drawer Sides 4x35mm	4
G	Bolt for Fitting Metal Legs and Cross Bar to Base Panel M6x28mm	14
P	Nut for M6 bolt	8









Fittings (not to scale)

Code	Item	Quantity
J	Allen Key - M6 Bolt	1
K	Drawer Stop	2
L	Screw for Fitting Anti-tilt Bracket 4x12mm	2
M	Anti-tilt Bracket	2
N	Spanner for M6 Nut	1
Q	Cam cover sticker	10



TELFORD CORNER DESK ASSEMBLY INSTRUCTIONS

General Hints & Tips



STEP 1

Diagram 1 shows the main assembly step. A large corner plate (1) is shown with screws (Ax10) being inserted into pre-drilled holes. Below the main plate, two side plates (3) and (5) are shown, each with four spacers (Cx4) being attached to them. The quantity "x2" is indicated for both side plates.

For this step:
Tools required


Fittings required

A x10

C x16

TELFORD CORNER DESK ASSEMBLY INSTRUCTIONS

STEP 2




For this step:
Tools required



Fittings required




B x6



Q x6

STEP 3



For this step:
Tools required




Fittings required




B x4

TELFORD CORNER DESK ASSEMBLY INSTRUCTIONS


STEP 4



For this step:
Tools required




Fittings required




D x10

STEP 5




For this step:
Tools required



N

Fittings required







G x8




P x8


STEP 6



For this step:
Tools required




Fittings required




A x4



B x4





Q x4




E x4

TELFORD CORNER DESK ASSEMBLY INSTRUCTIONS


STEP 7



For this step:
Tools required





Fittings required



G x6

STEP 8



For this step:
Tools required



Fittings required




K x2

STEP 9

WE RECOMMEND FIXING THIS DESK TO THE WALL

L	Screw for Fitting Anti-tilt Bracket 4x12mm	2	
M	Anti-tilt Bracket	2	





**CONSTRUCTION OF WALLS CAN BE VERY DIFFERENT SO FITTINGS ARE NOT SUPPLIED.
PLEASE CHOOSE SUITABLE FIXINGS TO SUIT THE YOUR HOME.
IF IN DOUBT CONSULT AN EXPERT**

Warning: Always ensure the area to be drilled is free from hidden electrical wires, water and gas pipes.

In the final position the desk is to be fixed, first place it against the wall.

Carefully mark the wall with a sharp pencil, dead-centre of the hole in the long leg of the metal anti-tilt bracket (M).




Loosen screw (L) a little. Holding desk firmly against the wall, push bracket (M) so the long leg touches the face of the wall.

Use your screw/fixing to fix bracket to wall.

Make sure bracket is touching wall evenly, then tighten screw (L).

For this step:

Tools recommended




Assembly Completed

Your Corner Desk is now completely assembled.

Periodically check to ensure that the components are in their proper position, free from damage.

Also, make sure the connectors are tight and secure.



Keep instructions for future reference

